


Fig.1






Fig.2






Fig.3


Get /driver.cgi HTTP/1.0

User-Agent: Browser1 (W_98)

Accept: text/html; */*

Host: www.***.co.jp

Fig.4






Fig.5






Fig. 6

PRINTER MODEL	OS TYPE	LOCATION ADDRESS
LP-1000	W_95	www.***.co.jp/driver/LP1000/w95.zip
	W_98	www.***.co.jp/driver/LP1000/w98.zip
	W_NT	www.***.co.jp/driver/LP1000/wnt.zip
LP-2000	W_95	www.***.co.jp/driver/LP2000/w95.zip
	W_98	www.***.co.jp/driver/LP2000/w98.zip
	W_NT	www.***.co.jp/driver/LP2000/wnt.zip

•
•
•




Fig.7






Fig.8






Fig.9

